# **ASSEMBLY INSTRUCTIONS**



Assembly Instructions for **F2173 Picnic Table (10 FT.)** 

To prevent scratching on any of the finished pieces, we recommend assembling the unit on packing material (paper and cardboard). Do not drag assembled unit on any surface. The assembly is a two person operation.

#### **Cleaning Recommendations**

For cleaning, use mild household cleansers or soap and water.

Do not use vinyl cleansers or protectants.

#### **Parts List**

# 1 – Table Top

#### 2 - Seats

# 2 – End Supports

# 1 – Center Support

4 – Cross Braces

# **Hardware Included**

# $\overline{26-5/16}$ Bolts

# 26 – 5/16" Nuts

#### 52 – Washers

#### 6 – Rubber Feet


#### **Tools Needed**

Ratchet with 1/2" socket

½" Wrench

Level

Rubber Mallet







211 N. Lindbergh Blvd. • St. Louis, MO 63131-7809 800-231-1327 • www.landscapebrands.com

# **ASSEMBLY INSTRUCTIONS**










Diagram #2

Note: Before assembling the nuts to the bolts, it is recommended that a light oil or petroleum jelly be applied to the bolt threads.

- 1. Place table top upside down on a level surface.
- 2. Align end support holes and center support holes with table top holes, as shown in Diagram #1.
- 3. Place bolts through holes and attach nuts to bolts, leaving nuts finger tight, with washers on both sides, as shown in Diagram #2
- 4. Align cross brace holes with center table top holes and the tab holes on the end supports and center supports.
- 5. Place bolts through holes and attach nuts to bolts, leaving nuts finger tight, with washers on both sides, as shown in Diagram #2.
- 6. Using the rubber mallet, insert the rubber feet in the outermost holes of the table supports.
- 7. Turn table right side up.
- 8. Level table top
- 9. Repeat steps 2 and 3 for seats.
- 10. Level seats.
- 11. Tighten all hardware. Retighten hardware two weeks after initial assembly.