

Quick Reference Guide

Universal ColorLogic® & CrystaLogic™



1. Voodoo Lounge (S) 10. Vivid Violet (F) 2. Deep Blue Sea (F) 11. Sangria (F)

3. Royal Blue (F) 12. Twilight (S)

4. Afternoon Skies (F) 13. Tranquility (S) 5. Agua Green (F) 14. Gemstone (S)

6. Emerald (F) 15. USA (S)

7. Cloud White (F) 16. Mardi Gras (S) 8. Warm Red (F) 17. Cool Cabaret (S)

9. Flamingo (F) (S) = Show (F) = Fixed Color

UCL

Pool: 14VAC, 60Hz, 70W

OR

Spa: 14VAC, 60Hz, 35W

Changing Modes (ColorLogic)

- Turn on lights, then off for 11-15 seconds (repeat 3 times)
- Turn light back on, light should blink 1of 4 colors (indicating light's mode)
 - 1. Universal ColorLogic (Red & White)
- 2. Color Logic 4.0 (Green & White)
- 3. ColorLogic 2.5 (Blue & White)
- 4. Pentair SaM (White & White)

Repeat 3 times



ON OFF (for 11-15s)

Note: To toggle light modes turn light OFF then back ON immediately, repeat until desired mode is selected turn off for two minutes to save

Syncing the Lights (ColorLogic)

 To synchronize the lights turn them on, then off for 11 - 14 seconds andthen back on



Quick Reference Guide - Programming

ColorLogic - Networked LEDs

18. Rainbow (S) 20. Custom Fade (S) 19. Harmony (S) 21. Custom Chase (S)

With module, network LEDs also offer these shows (on top of those mentioned on front page)

STEP 1

• Press until Configuration Appears, then hold down < & >

៉្រែក្រុះ-្រាក្រាក្រស់គ្នាថ្នា should appear after 5 seconds

- Press > until ColorLogic Config. appears, then press +; Find ColorLogic + to start sequence
- Once find is Completed Scroll to the > to label light(s), use the ± to change and > to navigate forward (helpful in complicated shows)

STEP 2

- Select AUX for light(s) and locate by pressing $> \begin{bmatrix} \text{Flux 1} & \text{Config.} \\ + \text{to view-change} \end{bmatrix}$ (example)
- Press + then press > until Aux 1 Relay | appears
- Assign LT(s) for this show by pressing ±, use ➤ button to advance
- Assign order of sequence using ±, use ➤ button to advance
 Step 2 should be repeated for any open relays we wish to use as ColorLogic shows

STEP 3

- Press while until Settings appears and press > until the first AUX containing a show appears Aux 1 Settings (example)
- Press > to navigate through program, color, speed, motion and brightness and the ± to make changes

Step 3 should be repeated for all relays identified as ColorLogic

To take a closer look or see other Hayward products please go to: www.hayward.com or call 1-800-432-8387

