





# FPS-5228

Standard Fireplace

## FREMONT




Shown with optional wood storage boxes which are not included.



**ROMANSTONE**  
HARDSCAPES®

Step by step instructions for assembling  
FPS-5228 on a prepared surface/base.  
If you have any questions, please visit:  
[www.romanstone.com](http://www.romanstone.com)

BUILD WITH ROMAN™



### This kit includes:

- 231 Euro (4x8x12)
- 2 Square Block (8x8x4)
- 2 Half Block (6x8x4)
- 4 Third Block (4x4x8)
- 2 Lintel Block w/notch
- 1 Cap Block (27x27)
- 2 6x9 Ledge Rock
- 13 6x12 Ledge Rock
- 42 Fire Brick
- 3 Cut Fire Brick
- 1 Angle Iron (34")
- 9 Tubes Adhesive

All sizes in this document are approximate.

When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**


Standard Fireplace

#### REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**Included  
with kit**

Tools Needed:  
Dead Blow Hammer  
Hammer  
Caulk Gun  
4 Foot Level  
Torpedo Level  
Square  
2 Ladders (6ft min.)



This set of instructions assumes you are building on a level grade on a level foundation.

Be sure to prepare foundation as set out in Romanstone's Base Preparation Guide. For any questions, visit your Romanstone Dealer, or find us on the web. [www.buildwith.romanstone.com](http://www.buildwith.romanstone.com).



Download a digital copy of these instructions. (PDF)



Download the Base Prep instructions. (PDF)



Download pictures of two guys building this kit. (PDF)

When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.




[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)


BUILD WITH ROMAN™	FPS-5228 Standard Fireplace	REVISIONS		Tools needed
		MM/DD/YY	REMARKS	
1		03/03/15	Total Rewrite in new style with color. TP	
2		06/04/15	2 SKU and QR update	
3		--/--/--	...	
4		--/--/--	...	
5		--/--/--	...	

All sizes in this document are approximate.


# Unit Size Color Key




The "Square Foot Unit." consists of three block as shown. By rotating this unit (SFU) we are able to build quickly and easily while keeping bond lines broken up. These will always be shown in a tan color.




Sometimes SFUs are broken up or can't be used. The Double Unit is the next preferred unit. Double Units are grouped for strength and speed in construction. They are always represented in green.




The Single Euro unit is the basis for all the construction, of course. When used in a single or non-standard configuration, you will see the Single Euro depicted in red.



Long Halfs are simply made by cutting a block along its center on the longest axis.



Cutting four inches off the short end of a Euro block will get you a Third block (and a Square one).



Cutting four inches off the short end of a Euro block will get you a Square block (and a Third one).

When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

ROMANSTONE  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

BUILD WITH ROMAN™

FPS-5228

Standard Fireplace

## REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

KEY1




All sizes in this document are approximate.


# Unit Size Color Key

When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.


ROMANSTONE  
HARDSCAPES®




12" x 12" Ledge Rock paver.  
Great to use as a large cap. Always shown in dark blue.




6" x 12" Ledge Rock paver.  
Great to use as a cap. Always shown in middle blue.




6" x 9" Ledge Rock paver.  
Great to use as a small cap. Always shown in light blue.



6" x 6" Ledge Rock paver.  
Great to use as a cap. Always shown in dark blue.



Lintel Block. There are two precision cut lintel block in your kit. They will be untumbled. "Age" the edges with a hammer before installing.



Fire brick. These hard refractory brick are very dense. Use them to line your firebox. Three come cut to a narrower width.

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

BUILD WITH ROMAN™

FPS-5228


Standard Fireplace

## REVISIONS


	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

KEY2

This is your foundation block. One cannot over emphasize the importance of properly installing this layer. **Be sure to take the time to ensure it is "perfectly" square and level.** Any imperfections here will continue to show up over and over as you build this kit.



**FRONT**



**FRONT**

When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**


Standard Fireplace

REVISIONS


	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**01**


Consider not gluing these central block of the fire box floor (depicted by the darker shaded block). They will be much easier to flip over or replace if needed down the road.



FRONT



The entire back of the fire-place is flush. There are no set-backs. Be sure to keep your fireplace plumb as you build. Use your 4' level and check often.




When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.





[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

The entire back of the fireplace is flush. There are no set-backs. This should aid in keeping your fireplace plumb as you build.

Always start building from the outside corners. This will help ensure you keep your structure plumb.



Any time you see a block with just the wide top showing, fret not, it is a Square Foot Unit (SFU). The unit is just turned where the that is the only block you see.



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**


Standard Fireplace

REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**03**





Start Here

**BUILD**

The side wall of  
fire brick will pass  
the rear wall as  
shown. Do not fill  
the air gap.

When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**


Standard Fireplace

REVISIONS



	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**04**

Always build the side walls of your fire box first. Start where the brick are denoted with an asterisk (\*). Abut the fire brick to the front blocks and work toward the rear wall. Then lay the back wall. The side walls will pass the face of the back wall. Do not fill the air gap in the corner. Only glue the back of the fire brick to the block behind them. Do not glue the fire brick to each other. Follow this procedure for the entire fire box.



**Fire Brick Pattern**



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**


**FPS-5228**

Standard Fireplace



REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**05**



Always start building from the outside corners. This will help ensure you keep your structure plumb.



The entire back of the fireplace is flush. There are no set-backs. This should aid in keeping your fireplace plumb as you build.

When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**


Standard Fireplace

REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...


**06**

chip  
this side





chip  
this side

Lintel Block with notches. Remember to chip the edges of the block with a hammer to give it an "aged" look. You only need to do this on the side opposite the notch. This will be the 8x4" side that is visible on the outside.



Lintel Block with notches. Be certain to face the notch cuts inward toward the fire box.



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

ROMANSTONE  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

BUILD WITH ROMAN™

**FPS-5228**



Standard Fireplace

REVISIONS



	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

07

Always build the side walls of your fire box first. Start where the brick are denoted with an asterisk (\*). Abut the fire brick to the front blocks and work toward the rear wall. Then lay the back wall. The side walls will pass the face of the back wall. Do not fill the air gap in the corner. Only glue the back of the fire brick to the block behind them. Do not glue the fire brick to each other. Follow this procedure for the entire fire box.



**Fire Brick  
Pattern**




When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®



[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

<b>BUILD WITH ROMAN™</b>	<b>FPS-5228</b>	REVISIONS		<b>08</b>
	Standard Fireplace	MM/DD/YY	REMARKS	
		1 03/03/15	Total Rewrite in new style with color. TP	
		2 06/04/15	2 SKU and QR update	
		3 --/--/--	...	
		4 --/--/--	...	
		5 --/--/--	...	





Place the angle iron such that the top of the angle leg is flush with the top of the lintel blocks. You may need to use coins as shims or add sand under the angle iron to make it flush. Be sure to roughly center the iron to the fire box opening. There will be extra room to allow for the angle iron to expand.



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**



Standard Fireplace

REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**09**

Always start building from the outside corners. This will help ensure you keep your structure plumb.




The entire back of the fireplace is flush. There are no set-backs. This should aid in keeping your fireplace plumb as you build.

When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.



[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)



Set these brick back to allow room for the angle iron. The top row of bricks will just pass the back wall a bit further.

When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**


**FPS-5228**

Standard Fireplace

REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**11**



Set these brick back to allow room for the angle iron. The top row of bricks will just pass the back wall a bit further.

When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**



**FPS-5228**

Standard Fireplace



REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**12**



**Fire Brick  
Pattern**



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**

Standard Fireplace

REVISIONS



	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**13**



You will need to set up TEMPORARY support blocks before proceeding to the next step.

**DO NOT GLUE THESE SUPPORT BLOCKS!**



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**




**FPS-5228**

Standard Fireplace

REVISIONS		
	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

Be sure to just catch the corner of the support block. It will be easier to remove later.

**DO NOT GLUE THESE SUPPORT BLOCKS!**



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**

Standard Fireplace




REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**15**

Be sure to just catch the corner of the support block. It will be easier to remove later.

**DO NOT GLUE THESE SUPPORT BLOCKS!**



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**

Standard Fireplace




REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**16**

## 6x8x4 Half Block

There are only two of these in the kit. Be sure they are not the square block. These are true half block. Be sure you get the right ones.



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**

Standard Fireplace

### REVISIONS


	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**17**

✱These block tend to want to rock back into the opening. Stack block to hold them into place until you place the next course.


**Now is a good time to take a break (lunch).**

This will allow the glue to set-up.



**4x4x8 Third Block**

**Keep the back wall of the fireplace flush. Rack the block in approximately 2" from each side.**



The back wall is ALWAYS flush.

When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**

Standard Fireplace




REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**18**



**Keep the back wall of the fireplace flush. Rack the block in approximately 2" from each side.**



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)


**BUILD WITH ROMAN™**

**FPS-5228**



Standard Fireplace

REVISIONS		
	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

Keep the back wall of the fireplace flush. Rack the block in approximately 2" from each side.



8x8x4 Square Block




When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.



ROMANSTONE  
HARDSCAPES®

www.buildwith.romanstone.com

Keep the back wall of the fireplace flush. Rack the block in approximately 2" from each side.



4x4x8 Third Block




Remove your support blocks from step 14.

When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.



ROMANSTONE  
HARDSCAPES®

www.buildwith.romanstone.com

**Keep the back wall of the fireplace flush. Rack the block in approximately 2" from each side.**



Remove your support blocks from step 14.



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**


**FPS-5228**

Standard Fireplace



REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**22**



Remove your  
support blocks  
from step 14.



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**




Standard Fireplace

REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**23**





When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**




Standard Fireplace

# REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**24**

Before gluing the top four blocks in place, TEMPORARILY lay out your crown blocks (blue shades) to ensure you have them properly positioned. **DO NOT GLUE THE CROWN BLOCKS AT THIS TIME.** Only glue the four cap support blocks (depicted in red). You want to pull your support block in about 1/2" to allow extra room when squaring your cap later.




When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.



[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)


**Remove the crown blocks before you install the large cap block.**

Allow the adhesive to fully cure before proceeding to lay the cap on these supports.



After the adhesive is set, place the cap block up-side-down on the top of your four block. Since the stone will be viewed from the ground looking up, the decorative side of the cap should be facing the ground. You may need to add some sand or coins to keep the cap from rocking on the block.

**Placing the cap is the hardest part of the entire build. Use ladders and/or scaffolding. You can use the ledges created by the racked block as a "strairway" to move the block up until the final heave.**



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)


**BUILD WITH ROMAN™**

**FPS-5228**



Standard Fireplace

REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...



Add the finishing blocks. The back and sides of the crown are identical from one side to the other. Center the mantle blocks. There will be a slight overhang on the front and sides.



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**


**FPS-5228**

Standard Fireplace


REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**27**



Allow the fireplace to cure for 72 hours before building your first fire. Then follow the 30/60/90 rule. Build a fire that will put itself out in 30 minutes. After it cools, build one that extinguishes itself in sixty minutes. Finally, build a 90 min-ute fire. Congratulations! Your fireplace is ready for use.



When constructing your kit, be sure to keep all blocks level, square, and plumb. Use a four foot level and check often. Starting on a level foundation is key. When gluing blocks together, be sure not to use too much adhesive - this will cause the blocks to "swim." A small bead is ideal.

**ROMANSTONE**  
HARDSCAPES®

[www.buildwith.romanstone.com](http://www.buildwith.romanstone.com)

**BUILD WITH ROMAN™**

**FPS-5228**

Standard Fireplace

REVISIONS

	MM/DD/YY	REMARKS
1	03/03/15	Total Rewrite in new style with color. TP
2	06/04/15	2 SKU and QR update
3	--/--/--	...
4	--/--/--	...
5	--/--/--	...

**28**